







Step 1 – Charging

1  • Remove the retrieval hook from inside the debris basket. (see step 14) • Unscrew the protective cap, and ensure the charging port is dry before charging.	2  • Insert the charger cable into the device, and keep your cleaner at least 3m away from the pool. • NOTE: Make sure the charging port is DRY before charging the device.	3  • Fully charge your device before first use. • This may take up to 2.5 hours to charge from empty. • The light on the charger will change from red to green to indicate it is charged.
--	--	--

Step 2 – Starting the device


4  • Screw the protective cap back on. • Note: Hand tight only. • Make sure the o-ring is present.	5  • Press the on/off button. The LED will turn a solid blue. • Put the device into the pool within 3 min, otherwise, it will power off. • The default cleaning mode is wall then floor. • To use the app proceed to step 6 before putting the device into the water.
---	---

Step 3 – HY-CLOR CORDLESS ROBOTS App set up
(If you do not need to preset the cleaner you can skip this step)

6  • Please download HY-CLOR CORDLESS ROBOTS App and set your cleaning mode before putting the cleaner into the pool. • Register your account as per App direction. • Link your device as per App direction. • Make sure you setup the cleaner via the app before putting it into the water.	7  • Enable your mobile phone's Bluetooth. • Keep your device out of water and within range of Bluetooth. • Your device will turn solid purple after a successful connection to the app. • The app will not work while the cleaner is underwater. • Note: Wi-Fi is only needed for updates. Connection not required otherwise.	8  • Customise your cleaning patterns via App. • The i4 will blink purple when each setting has successfully been accepted. • The i4 will remember the last setting saved even if turned off.
---	--	---


Step 4 – Submerging the device

9



- Submerge the device into the pool gently via the handle.
- Do not throw the i4 into the pool.


10



- Wait for the i4 to auto calibrate. Approx 30 seconds.
- The LED will start to slowly blink/flash blue and start its cleaning cycle.


Step 5 – Removal from the pool

11




- The cleaner will auto park at the nearest wall when the cleaning cycle has finished. It will blink yellow indicating low battery or auto parking is being attempted.

12



- Insert the retrieval hook into a standard pool pole.


13



- Hook the cleaner out via the handle to water level. Then use hands to slowly pull the cleaner out of the pool to allow the water inside to escape.


Step 6 – Cleaning the internal filter basket and i4 cleaner

14



- Clean the internal filter basket as soon as it is retrieved from the pool. Give the entire i4 cleaner a wash with fresh water.
- This will help the cleaner's longevity greatly.
- Make sure the charging port is dry before charging the device.

15



- Store the cleaner in a well ventilated place and keep it out of direct sunlight or inclement weather.
- Charge the device at least every 1-3 months to maintain battery performance during the off-season or while in storage.